

# Safety alert

SA # 2015-1

# Mixing metric/imperial brake airlines and fittings May 2015

| Priority:  | Urgent □ | Necessary [ | ☑ For informa | tion 🗆  |                 |
|------------|----------|-------------|---------------|---------|-----------------|
| Circulate: | Driver □ | Operator □  | Workshop 🗹    | Parts 🗹 | Fleet Manager ☑ |

## The incident or issue:

Through the work of its Industry Technical Council, the ATA has been alerted to a number of instances where newly purchased and installed fittings/airlines have failed to seal correctly.

These installations leaked excessively while the vehicle was under test in the workshop and were replaced without further incident. However, if undetected, these leaks could cause onroad complications such as the unintended activation of emergency braking systems.

### Incident cause:

Metric airlines and their fittings have become available through a range of parts networks to support European models. However, the Australian market typically uses imperial sizes of airlines and fittings.

Confusion can arise given the similar, but not equivalent, sizes of these airlines. The metric 12 mm line will appear to accept the imperial  $\frac{1}{2}$ " olive, which has an equivalent to 12.7 mm outside diameter.

The mismatch of fittings and airlines will result in a loss of integrity of the assembly. Additionally, the metric line has a smaller inside diameter restricting air flow, which potentially results in the vehicle not being ADR (Australian Design Rules) compliant. This is shown in the table below.

|       | Outside Diameter | Inside Diameter |
|-------|------------------|-----------------|
| 6 mm  | 6.00             | 4.00            |
| 1/4"  | 6.35             | 4.32            |
| 8 mm  | 8.00             | 6.00            |
| 5/16" | 7.94             | 5.90            |
| 12 mm | 12.00            | 9.00            |
| 1/2"  | 12.70            | 9.55            |
| 19 mm | 18.00            | 14.00           |
| 3/4"  | 19.05            | 14.38           |

The table above lists only a selected range of sizes and is not intended to be inclusive.

#### **Solution:**

It is essential that airlines and fittings use the same applicable standard (metric or imperial) and airline size. Workshop staff should check the size printed on the airline before selecting matching fittings.

| Follow-up actions:  |  |
|---|--|
| ☐ Separate metric / imperial fittings/airlines and label stores correctly |  |
| ☐ Educate staff about the differences                                     |  |

DISCLAIMER - ATA makes no representation and provides no warranty that the information and recommendations contained in this Truck Industry Technical Alert are complete or without exception. Reliance or use upon the information or recommendations is voluntary and the user accepts all risks and responsibility for any such reliance or use and to the maximum extent permitted by law ATA excludes all liability to any person arising directly or indirectly out of any such reliance or use.

(c) 2015 Australian Trucking Association - This work is copyright. Apart from uses permitted under the Copyright Act 1968, no part may be reproduced by any process without prior written permission from the Australian Trucking Association. Requests and inquiries concerning reproduction rights should be addressed to the Communications Manager, Australian Trucking Association, 25 National Circuit, Forrest ACT 2603 or ata@truck.net.au.